


客户代码:	
资料名称: -KW059 英文说明书 (通用)	
类别	规格
展开尺寸	540×115mm
成品尺寸	90×115mm /5折
材质	128g双铜
颜色	CMYK 4色
语言	英文
其它	


115mm

540mm


MAINTENANCE



1. Unplug the adaptor and press the mist and light button to turn off the product.
2. Remove the cover.



3. Empty water via the water discharge groove.
4. Use a clean swab to clean the ceramic plate.
5. Gently wipe the tank out with a soft cloth.



TROUBLESHOOTING

Symptom	Possible Cause	Solution
Power supply is not connected		Plug the power and press the power button
No Mist	Insufficient water	Refill the water tank
	There's too much water that it even exceeds the Max. water level line	Dump the redundant water
The atomization mouth is blocked		Clean the mouth and keep it ventilated

WARNING

In case of any abnormal observations such as smoke, peculiar smells or noise, stop using the unit immediately to avoid the risk of an accident such as fire or electric shock. You should unplug the adaptor immediately and contact your local dealer. Never wrap the adaptor or Aroma Diffuser with cloth or paper, as blocking the ventilation could increase the risk of a fire. Never attempt to disassemble or repair the product. In case of internal inspection or repair becoming necessary, please contact your local dealer. Please keep the product out of the reach of children to avoid risk of any injury. Your Aroma Diffuser should be cleaned regularly and kept clean and dry when not in use.


IMPORTANT!

Corrosive oils such as Citronella may cause damage to the ceramic disc if left in the reservoir when not operating the unit. This type of damage will not be covered under the warranty. This Aroma Diffuser must be cleaned after each use.

ONE YEAR WARRANTY

This limited warranty does not cover any damage, deterioration or malfunction resulting from any alteration, modification, improper use or maintenance, misuse, accident, exposure to excess moisture, fire, lightning, power surges, or other acts of nature. This limited warranty lasts for one (1) year from the date of original purchase of this product. In order to pursue any remedy under this limited warranty, you must visit www.scentworks.co.za/warranty and complete the warranty activation form or email your contact information to warranty@scentworks.co.za. Also you must produce an original, dated receipt as proof of purchase from an authorized Scentworks dealer. Scentworks Pty Ltd at its sole option, will provide one of the following three:

1. Elect to repair or facilitate the repair of any defective parts within a reasonable period of time, free of any charge for the necessary parts and labour to complete the repair and restore this product to its proper operating condition.
2. Replace this product with a direct replacement or with a similar product deemed by ourselves to perform substantially the same function as the original product.
3. Issue a refund of the original purchase price less depreciation to be determined based on the age of the product at the time remedy is sought under this limited warranty. The maximum liability under this warranty is the retail purchase price paid for this item.



115mm

540mm

CLARITY
LUXURIOUS SCENT DIFFUSER

The Clarity ultrasonic oil diffuser uses ultrasonic technology to turn water and essential oils into fine micro-particles, diffusing aroma as mist without heat. Since this process of diffusing essential oils is also smokeless and heatless, the purity and health benefits of these oils remain intact.


Simply add a few drops of your favourite fragrance oil into the water filled reservoir, replace the cover and push the buttons to control mist intensity and light. Auto shut off feature gives you peace of mind.

SCENTWORKS (PTY) LTD
74 Kyalami Boulevard, Kyalami Business Park, Midrand, Gauteng, South Africa
info@scentworks.co.za

SPECIFICATIONS


Item No.: AURA Clarity
Product Size: Φ 113 x 96mm
Voltage: DC 5V
Power: 5W
Water Capacity: 100ml
Run time: Up to 4 hours continuously

01. Cover
02. Max. water level line
03. Vent hole
04. Button
05. Power port



OPERATING PROCEDURE


IMPORTANT NOTES BEFORE USE:
Place the Aroma Diffuser on an even surface. Always fill with tap water at room temperature. Water-soluble essential oils are recommended. Please contact your local dealer for further information.



1. Remove the cover.


DO NOT EXCEED THE MAX. WATER LEVEL LINE

2. Fill the water tank with water to the indicated water line.
3. Add 3-5 drops of your favourite essential oil into the water.
4. Replace the cover.




5. Plug the adaptor in.

Note: Do not lean, move or attempt to empty or refill during operation.



6. Push down on the top of the diffuser to switch it on or to change the mode.



Number of clicks	Mist	Light
Once	On, constant	Light on
Twice	On, constant	Light off
Three times	Mist off	Light off